

# K14 DISHWASH PRESOAK POWDER

## SPECIALLY FORMULATED PRE-SOAKER FOR THE REMOVAL OF DRIED ON OR HEAVY SOILING PRIOR TO WASHING THROUGH A DISHWASHING MACHINE.

- Removes stubborn stains such as starch and burnt-on food residues from cups and cutlery.
- Contains a blend of light alkalis and scale inhibitors.
- Can be used to de-tarnish silverware.
- Free-flowing powder.

### USE INSTRUCTIONS

#### SOAKING

1. Fill a soak reservoir with warm water (40-50°C).
2. Add 10 to 20g of Presoak Powder per 1 litre of water.
3. Immerse the items in the solution for 10-15 minutes, depending on the degree of soiling.
4. Pass items through the dishwashing machine as normal.

#### SILVER DE-TARNISHING

1. Place aluminium foil or block in the base of a non-metallic container. Fill with warm water (40-50°C).
2. Add 10 to 20g of Presoak Powder per 1 litre of water.
3. Immerse silverware for 10-15 minutes. Make sure that the items are in contact with the aluminium but not with each other.
4. Rinse off with water or pass items through the dishwashing machine.

### SAFE HANDLING AND STORAGE

- See information on the right.
- Full guidance on the handling and safe use of the product can be obtained from the Safety Data Sheet.
- Store in original container.
- Avoid extremes of temperature.

### TECHNICAL INFORMATION

APPEARANCE	Blue powder
PH	>11.0
RELATIVE DENSITY	N/A
ODOUR	Characteristic
SOLUBILITY	Fully miscible in water

The above data is typical of normal production and should not be taken as a specification

#### SKU:

CLEPRESOAK



#### HAZARD AS SUPPLIED

Causes serious eye irritation. Wear gloves for prolonged use.

#### HAZARD WHEN USED AT RECOMMENDED DILUTION

Not classified. Wear gloves for prolonged use

#### PACK SIZES



10KG